

AUTOMATIC COCKTAIL MIXER INSTRUCTIONS FOR USE


IMPORTANT SAFETY INSTRUCTIONS

- 1. Use this unit only for its intended use as described in this manual.
- 2. The unit should be placed away from direct sunlight or heat sources such as radiators, electric heaters, heat registers, stoves, or other units (including amplifiers) that produce heat.
- 3. Keep fingers away from moving parts at all times.
- 4. Do not drop or strike the clear Reservoir on a hard surface as it may crack or shatter.
- 5. Please discard product immediately if Reservoir is cracked or broken.

CAUTION: This product has moving parts.

LOCATION OF PARTS AND CONTROLS

- 1. Mix Button
- Pour Button (when simultaneously pressed with the Mix button)
- 3. Battery Compartment
- 4. Cover
- 5. Reservoir
- 6. Liquid Stirrer
- 7. Suction Tube
- 8. Measurement Guide
- 9. Pour Spout
- 10. LED Operational Indicator



USING THE COCKTAIL MIXER

INSTALLING THE BATTERIES

- Using a Phillips head screwdriver (not included), unscrew the battery compartment cover's access screw.
- Remove the battery compartment cover and install 4 AA batteries according to the polarity indicators inside the compartment.
- Replace the battery compartment cover and secure it with the access screw using a Phillips head screwdriver.

READY TO MIX AND POUR!

- 1. Unscrew and remove the cover. Remove the liquid stirrer and suction tube from the reservoir.
- 2. Fill the reservoir with your favorite drink combination.
- 3. Replace the cover.
- Press the mix button to mix your drink. The LED light will illuminate while the Cocktail mixer is in action.
- 1. Hint: For a chilled beverage, you may mix your drink while the Cocktail Mixer's reservoir is "on ice" simply place the reservoir in ice and press the Mix button.
- IMPORTANT! DO NOT add ice cubes or ice chips to the Cocktail Mixer's reservoir or submerge the entire unit in ice/water. Doing so may damage the motor.
- Aim the pour spout into the top of a chilled, ice filled glass and press the pour and mix buttons simultaneously to dispense your mixed drink. The LED light will illuminate while the liquid is dispensing.
- Caution: Liquid may pour out of the spout unexpectedly if you are mixing a carbonated drink.
- 6. Enjoy!

CLEANING THE PUMP COCKTAIL MIXER

IMPORTANT: Wash the Cocktail Mixer before first use.

- 1. Unscrew and remove the cover. Remove the liquid stirrer and suction tube from the reservoir.
- Fill the reservoir to the half-way mark with warm, sudsy water and place the cover back onto the reservoir.
- 3. Press the mix button to mix the warm, sudsy contents. LED light will illuminate.
- 4. Aim the pour spout back into the sink and dispense the sudsy water by pressing both the mix and pour buttons together. The LED light will illuminate. Repeat this process with just warm water until suds no longer appear.
- 5. Unscrew and remove the cover. Remove the liquid stirrer and suction tube from the reservoir and carefully dry each piece, including the silicone gasket.
- Make sure that the mixer is completely dry before storing. Store loosely assembled in a dry place.
- IMPORTANT: NOT DISHWASHER SAFE. DO NOT submerge the cover with the battery compartment in water. Use only mild dish detergent.

TERMS AND CONDITIONS

Epicureanist LLC ("Seller") and the person or entity that acquires these goods from Seller ("Purchaser") hereby fully agree to the following terms and conditions of the sale: Shipping fees are the responsibility of the Purchaser whether freight prepaid or freight collect. Seller assumes no responsibility for the goods sold to the Purchaser once the goods have left the Seller's premises, including, but not limited to, late delivery by the moving carrier, or for events caused by any difficulty carrier incurs in attempting to fit the goods into the Purchaser's place of business or residence due to the size of the goods or otherwise. Purchaser assumes all responsibility for delivery, payment of freight, access, measurement, installation, hook-up, wiring, moving and storage of the goods. The transportation of all goods is subject to the terms and conditions which the moving carrier imposes on Purchaser including, but not limited to, additional charges imposed per flight of stairs, and/or additional charges resulting from the carrier's inability to safely and/or adequately use the building elevator to lift the goods to an upper floor. Any claim for damages incurred during shipment by the carrier of the goods are insured and handled directly with the carrier and must be noted at time of delivery. Any damages due to manufacture defects will be handled directly with Epicureanist, subject to the limited warranty.

All sales are final, and unless authorized in writing by the Seller, Purchaser may not return the goods, under any circumstance. If Purchaser refuses to accept the goods, under any circumstance, the Purchaser is liable for the return and cost of freight both ways, and if Seller does take back the goods, there will be a restocking/service fee that is 35% of the purchase price of the goods. Built-to-Order products (including Cabinets, Racking, and Accessories) are non-returnable. Purchaser must notify Seller of non-conforming goods within four days of delivery, after which time all goods are deemed accepted. If an order has been placed and production has started, cancellation of your order will be a 15% charge.

If Purchaser tenders payment with a check that has insufficient funds (NSF), or stops payment on a check or credit card for any reason, Purchaser agrees to pay for all costs associated with the Seller's connection or litigation of such a claim, including without limitation extra damages, court costs and attorneys' fees. Finance charges begin the date of invoice. Collection fees plus NSF fee of \$50 will be added to your invoice, which you agree to promptly pay. Title to the goods does not pass until payment is received in full by Seller and Seller retains a security interest in the goods until they are paid for in full.

LIMITED WARRANTY: Seller warrants that the goods will be free of defects in materials and workmanship as follows: Furniture style (wood) wine units: all cooling unit parts for a period of 5 (five) years: cabinetry and labor (uninstalled) for a period of 12 (twelve) months from date of sale. For the metal cabinet wine units; parts and labor for cooling system and cabinetry for a period of 12 (twelve) months from date of sale. Thermoelectric Units: 90 (ninety) days from the date of sale. (This includes Wine Coolers, Beer Dispensers, Humidor, Portofino Wood Cellars, and Refrigerators). Wine-Mate Split Systems and installed products are parts only for 1 year, no labor. Other Wine-Mate Cooling Systems are 5 years parts, 1 year labor. Element Grills (via Element Products LLC) have a 1-year comprehensive parts warranty on entire product. Three years limited parts warranty covering the stainless burner and a thirty day limited parts warranty on grill accessories. Wine Accessories and Racking Systems are not warranted. For a scratch and dent/refurbished unit, warranty is 3 months from your dated invoice (parts for function only, not cosmetic). There is no warranty on parts purchased separately. Removal and re-installation of unit is not included in warranted labor. Purchaser's exclusive remedy is limited, at Seller's option; to repair or replace defective part[s] with either new or factory reconditioned part[s]. Purchaser is responsible for shipping the unit pre-paid to designated facility and Seller will pay return shipping charges in the continental United States for items repaired under warranty within 12 (twelve) months from date of sale. Since the natural variation in texture, density, grain, color, tone and shade of wood is unavoidable; Seller does not guarantee the texture, color, tone or shade of the wood: nor does seller quarantee the colorfastness of wood or against peeling, chipping, cracking or scratching. Note: Unfinished wood is subject to warping; all wood surfaces must be sealed before placing cellar into service. Improper placement of the unit will void the warranty. This limited warranty does not cover damage due to such things as accident, misuse, abuse, mishandling, neglect, acts of God, fires, earthquakes, floods, high winds, government, war, riot or labor trouble, strikes, lockouts, delay of carrier, unauthorized repair, or any other cause beyond the control of the Seller, whether similar or dissimilar to the foregoing. Seller is not responsible for any damages caused to Seller's property resulting from the good. This limited warranty applies only inside the Continental US. (Alaska, Puerto Rico and Hawaii are not warranted.)

For Element/Fuego Grills, warranty is 1 year, with 3 years on the burner. If grill is defective and unused plus all packaging and parts are intact, we will either replace the grill or provide service to repair the grill. Returned product must accompany all original packaging and parts and is subject to our 35% restocking fee (and freight both ways).

With Wine-Mate products, if the customer calls and the product is "defective", you must obtain a letter from your qualified refrigeration technician at the customers cost, to verify that the unit was installed properly, with proper ventilation and the unit is truly malfunctioning due to manufacture defect.

Purchaser understands and acknowledges that the goods sold here are wine cellars, cigar humidors, and/or other similar units which house wine or cigars. Purchaser assumes all risk of using these units, including risk of spoilage, humidity variations, temperature variations, leaks, fire, water damage, mold, mildew, dryness and similar and any other perils that might occur.

Seller is not responsible for incidental or consequential damages, and there are no warranties, expressed or implied, which extend beyond the Limited Warranty described above. Warranty and liability are non-transferable. The implied warranties of merchantability and of fitness for a particular purpose are hereby expressly disclaimed. Some states do not allow the exclusion of incidental or consequential damages, or a waiver of the implied warranties of fitness and/or merchantability, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. Seller disclaims any indemnification for claims of infringement of any intellectual property of protectable nature.

In the event of any dispute between Seller and Purchaser arising out of or relating to these terms and conditions or to the goods sold generally, Purchaser must first file a written claim with Seller within ten days of the occurrence giving rise to the claim and wait an additional thirty days for a response before initiating any legal action. The sale and all terms are subject to California law. Any legal proceeding arising out of or relating to these terms and conditions or to the goods sold generally shall be brought solely and exclusively in the County of Los Angeles. In no event may Purchaser initiate any legal proceeding more than six months after the occurrence of the event giving rise to the dispute.

The above terms and conditions are the only ones governing this transaction and Seller makes no oral representations of any kind. These Terms and Conditions can only be modified in writing, signed by both Purchaser and Seller. 10/12

SERVICE AND IMPORTANT NOTICE

The manufacturer has a policy of continuous improvement on its products and reserves the right to change materials and specifications without notice.

Contact info@epicureanist.com with any questions or visit www.epicureanist.com



17621 S. Susana Road Rancho Dominguez, CA 90221 www.epicureanist.com

WARNING:

Please do not place the unit within reach of children.

For adult use only.

Epicureanist is a trademark of Epicureanist LLC. All products, features, and services are subject to change without notice. We cannot guarantee the accuracy of the contents of this document. We disclaim liability for errors, omissions, or future changes.

©2012 Epicureanist LLC. All rights reserved.