

Vinotemp®

VT-200 Control Board Replacement & Temp Sensor Probe Replacement

1. Remove the screws from the back panel.



2. Remove the back panel.



3. Remove the screws from the control board cover.



4. Remove the cover of the control board.



5. Disconnect the terminal on the control board.



6. Remove the screws from the control board.



7. Replace the control board with a new one and fasten the screws.



8. Connect the terminal on the control board.



9. Place the control board cover back into position and fasten it with the screws.



Replacing the Thermostat Sensor



1. Remove all racks from the cabinet.



2. Remove the four screws on the evaporating board.



3. Remove the evaporating board.



4. Disconnect the wire.



5. Replace the thermostat sensor.

